

# VR Hub Quick Set Up Guide

## 1 Check for Windows Updates

1. Press Windows Key + I to open Settings.
2. Go to Update & Security → Windows Update.
3. Click Check for updates and install anything available.
  - Restart your PC if required.

## 2 Update Graphics Drivers

### Option A: NVIDIA Graphics Card

1. Right-click your desktop → NVIDIA Control Panel (or GeForce Experience if installed).
2. In GeForce Experience, go to Drivers tab → Check for updates → Install.

### Option B: AMD Graphics Card

1. Download Intel Driver & Support Assistant from Intel's website.
2. Run scan → Install available updates.

### Option C: Intel Graphics

1. Download Intel Driver & Support Assistant from Intel's website.
2. Run scan → Install available updates.

## 3 Connect Meta Headset to Computer

### 1. Plug in your headset

- Use the USB-C Link Cable (or an approved high-speed cable).
- Make sure your computer is plugged in and charging.

### 2. Open the Meta Quest Link

- Put on your headset.
- Select "Enable Link" when prompted.
- If the prompt doesn't appear, open the Meta app on your PC → Devices → Quest Headset

### 3. Launch the VR Hub or other apps

- Once connected, open the VR Hub on your PC.
- Choose your simulation and hit Play.

## Quick Tips

- Keep your USB cable securely connected—loose connections can cause the headset to disconnect.
- Restart both the PC and headset if you have connection issues.
- Always keep Windows + GPU drivers updated for best VR performance.

# Prepare Accounts & Software

## Create a Gmail Account (if needed)

- Each headset should have its own Gmail account.
- Create a new Gmail account if you don't already have one.
- Log in to the headset using this Gmail account.

## Install the Oculus (Meta) App on Your Phone

- Download the Oculus app from the App Store (iOS) or Google Play (Android).
- Log in using the same Gmail account as the headset.
- Pair your phone with the headset for management and updates.

## Download PC Software

- On your computer, go to the Meta Store Setup Page.
- Download and install the Meta Quest Link / Air Link software.
- Log in with the same Gmail/Meta account to connect your headset.



Tip: Keeping accounts consistent (same Gmail for headset, phone app, and PC software) prevents login issues and makes setup smoother.



## Important Reminders

- Offline mode lasts for five days before needing to go online to log-in again.
- Before an event, make sure to be logged in to the VR Hub, and that the simulations are up-to-date.
- Ensure laptop remains plugged-in during use.